

# Use of the PowerPlex® Fusion 6C System to Amplify DNA from Storage Card Punches

Instructions for Use of Products DC2705, DC2720 and DC2780.



Quick Protocol

## Protocol for Amplification and Analysis of DNA from Storage Card Punches

This document is a quick protocol for experienced users to amplify DNA directly from storage card punches in a 12.5µl reaction volume. Quick protocols are also available to amplify extracted DNA and DNA from swabs. For complete protocol information and troubleshooting tips see the *PowerPlex® Fusion 6C System Technical Manual #TMD045*, which is available online at:

[www.promega.com/protocols/](http://www.promega.com/protocols/)

Prior to using a PowerPlex® Fusion 6C System for the first time, thaw all pre-amplification and post-amplification components. Store reagents at 2–10°C, where components are stable for 6 months. Do not refreeze.

**Note:** Amplification of DNA from FTA® card punches in a 12.5µl reaction volume requires 5X AmpSolution™ Reagent (Cat.# DM1231).

### Before You Begin

The PowerPlex® Fusion 6C System is compatible with the following sample types:

#### FTA® Sample Types

Buccal cells collected on FTA® cards with Whatman EasiCollect™ or Fitzco Sampact™ devices

Buccal cells collected with swabs transferred to FTA® or Indicating FTA® cards

Liquid blood (from collection or storage Vacutainer® tubes or finger sticks) spotted onto FTA® cards

#### NonFTA Sample Types

Buccal samples on Bode Buccal DNA Collector™ devices

Blood and buccal samples on nonFTA cards (e.g., S&S 903)

No preprocessing steps are required for FTA® card punches. For nonFTA cards, the punches must be preprocessed as described below. For complete protocol information see the *PunchSolution™ Kit Technical Manual #TMD038*, which is available online at:

[www.promega.com/protocols/](http://www.promega.com/protocols/)

1. Add 10µl of PunchSolution™ Reagent to each 1.2mm punch placed in a well of the 96-well reaction plate.

**Note:** Do not cover the plate or place the plate in a thermal cycler with a closed, heated lid.

2. Incubate plate at 70°C for 30 minutes or until wells are dry.

### PCR Setup

1. Centrifuge pre-amplification component tubes briefly, and then vortex for 15 seconds before each use. Do not centrifuge after vortexing.

2. Determine the number of reactions including positive and negative controls. Add 1 or 2 reactions to this number.

3. Prepare the PCR amplification mix by combining the components as shown below.

PCR Amplification Mix Component	Volume per Reaction	×	Number of Reactions	=	Final Volume
Water, Amplification Grade	5µl	×		=	
PowerPlex® Fusion 6C 5X Master Mix	2.5µl	×		=	
PowerPlex® Fusion 6C 5X Primer Pair Mix	2.5µl	×		=	
5X AmpSolution™ Reagent	2.5µl	×		=	
<b>Total volume</b>	<b>12.5µl</b>				

# Use of the PowerPlex® Fusion 6C System to Amplify DNA from Storage Card Punches

Instructions for Use of Products DC2705, DC2720 and DC2780.



Quick Protocol

## PCR Setup (continued)

4. Vortex the PCR amplification mix for 5–10 seconds, and then add 12.5µl of PCR amplification mix to each reaction well.
5. For FTA® storage cards, add one 1.2mm punch for whole blood or buccal samples to the appropriate reaction wells. For nonFTA card punches, add the PCR amplification mix to the reaction well containing the PunchSolution™ Reagent-treated punch.
6. For the positive amplification control, vortex the 2800M Control DNA, and then add 1.0µl (10ng) to a reaction well containing 12.5µl of PCR amplification mix.

**Note:** Optimization of the amount of control DNA may be required, depending on cycling conditions and laboratory preferences.

7. Reserve a well containing only PCR amplification mix as a negative amplification control.
8. Seal or cap the plate, and briefly centrifuge the plate.

### Notes:


## PCR

The following protocol was developed for use with the GeneAmp® PCR System 9700 with a silver or gold-plated silver sample block with Max Mode as the ramp speed, the Veriti® 96-Well Thermal Cycler with a 100% ramping rate and the 9700 Simulation Mode as the ramp speed on the ProFlex™ PCR System.

1. Program the thermal cycler with the following conditions. Refer to the technical manual for more information. When amplifying DNA from punches we recommend using 25 cycles. Optimize the cycle number as required.

**Note:** NonFTA storage card punches may require fewer amplification cycles than FTA® card punches.

**Optional:** Record the cycle number as optimized in your laboratory.



**Figure 1. The thermal cycling protocol for the GeneAmp® PCR System 9700, Veriti® 96-Well Thermal Cycler and ProFlex™ PCR System.**

2. Proceed with fragment analysis, or store amplified samples at –20°C in a light-protected box until ready to analyze.

### Notes:

# Use of the PowerPlex® Fusion 6C System to Amplify DNA from Storage Card Punches

Instructions for Use of Products DC2705, DC2720 and DC2780.



Quick Protocol

## Instrument Setup and Sample Preparation

A passing spectral calibration must be generated using the PowerPlex® 6C Matrix Standard (Cat.# DG4900) prior to sample analysis. See the *PowerPlex® 6C Matrix Standard Technical Manual #TMD046* for more information.

### Instrument Setup

1. For the Applied Biosystems® 3500 or 3500xL Genetic Analyzer, set the oven temperature to 60°C, and then select “Start Pre-Heat”. When the Oven Temperature and Detection Cell Temperature turn green, you may proceed with the first injection.
2. Use the following parameters when setting up the instrument. Refer to the instrument user’s manual for additional details.

Genetic Analyzer	Run Module	Dye Set	Injection Parameters <sup>1</sup>	Run Parameters
Applied Biosystems® 3500	HID36_POP4	Promega J6	1.2kV, 15 seconds	13kV, 1,500 seconds
Applied Biosystems® 3500xL	HID36_POP4xl	Promega J6	1.2kV, 24 seconds	13kV, 1,500 seconds
Applied Biosystems® 3130 and 3130xl with Data Collection Software Version 4.0 and DC v4 6-Dye Module v1 License	HIDFragmentAnalysis36_POP4	J6 <sup>2</sup>	3kV, 5 seconds	1,500 seconds

<sup>1</sup>Injection time may be modified to increase or decrease the observed peak heights.

<sup>2</sup>Confirm that the active dye set is the file generated for the PowerPlex® 6-dye chemistry.

**Optional:** Record the injection conditions as optimized in your laboratory.

### Notes:

## Sample Preparation

Prepare samples for capillary electrophoresis immediately before loading.

1. Centrifuge post-amplification component tubes briefly, and then vortex for 15 seconds before each use. Do not centrifuge after vortexing.
2. Calculate the number of samples including the number of allelic ladders per run. Add 1 or 2 samples to this number.
3. Prepare a loading cocktail by combining and mixing the WEN ILS 500 and Hi-Di™ formamide. You may need to optimize the volume of WEN ILS 500.

Component	Volume per Sample	×	Number of Samples	=	Final Volume
WEN ILS 500	0.5µl	×		=	
Hi-Di™ formamide	9.5µl	×		=	
<b>Total volume</b>	<b>10µl</b>				

**Optional:** Record the volume of WEN ILS 500 per sample as optimized in your laboratory.

# Use of the PowerPlex® Fusion 6C System to Amplify DNA from Storage Card Punches

Instructions for Use of Products DC2705, DC2720 and DC2780.



*Quick Protocol*

## Sample Preparation (continued)

4. Vortex the loading cocktail for 10–15 seconds, and pipet 10µl of formamide/ILS mix into each well.
5. Add 1µl of amplified sample (or 1µl of PowerPlex® Fusion 6C Allelic Ladder Mix). Cover wells with appropriate septa, and centrifuge plate briefly.
6. Denature samples at 95°C for 3 minutes, and then immediately chill on crushed ice or freezer block or in an ice-water bath for 3 minutes. Denature samples just prior to loading the instrument.
7. Place the plate on the instrument, and start the capillary electrophoresis run.

### Notes:

## Data Analysis

The panels, bins and stutter text files needed for data analysis using GeneMapper® *ID-X* software, version 1.2 or higher, are available for download at: [www.promega.com/resources/tools/genemapper-id-software-panels-and-bin-sets/](http://www.promega.com/resources/tools/genemapper-id-software-panels-and-bin-sets/)

To acquire the panels, bins and stutter files needed for data analysis using GeneMarker® HID Software, contact SoftGenetics at: [www.softgenetics.com](http://www.softgenetics.com)

Additional protocol information in Technical Manual #TMD045, available online at: [www.promega.com](http://www.promega.com)

